

## Assembly Instruction For 87595/87597/87599

- 1. Disconnect the power by turning off the circuit breaker.
- 2. Install mounting bracket to outlet box with mounting screws provided. Make sure the 2 screws (B) are threaded in from the opposite side.
- 3. Wire fixture (A) wires to wires in outlet box. Black wire from Driver to Black wire and White wire from Driver to White wire. Green/Bare copper wire is for Ground. Do not connect the RED and BLACK wire to the wires from outlet box, it might short circuit the Driver.
- 4. Install future (A) to bracket. Aligned fixture (A) holes to screws (B) and secure with Ball Nut (C).
- 5. Attach Plastic Diffuser (D) to fixture (A). Turn clockwise to secure the Plastic Diffuser (D) in place.

