

## Assembly Instruction Sheet #IS-ANW8603AN For Style ANW8603AN

Please go to www.quoizel.com for product cleaning tips. Go to the Care + Maintenance selection. Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses. Light Source: (3) Medium Base Decorative Filament 60W bulb (provided), Maximum 100W, Alternate bulb (3) 23W CFL Maximum. Estimated Assembly Time: 30-45 minutes Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts. A Warnings and Cautions Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result. Package Contents **STEP 2 - Wire Connections** Edison Bulb 1M D х3 A. Use standard wire connectors (not included) to make all wire connections. (Connectors are not included with fixture.) Twist connectors until wires are tightly joined together. Wrap each Shade Lock 6 Е connection with approved electrical tape and carefully stuff all the x 3 R Screw connected wires between Inner Backplate (A) and Fixture Body (C). x 2 Lock White wire White wire Screw Inner Backplate from supply Α from fixture x 9 M x 1 Black wire Black wire from from fixture supply (or Red) W Ground wire Ground wire Fixture from fixture from supply С Body Figure 2 x 1 STEP 3 - Install Shades, Bulbs and **Bulb Shields** STEP 1 - Install Inner Backplate and Fixture Body A. Place Shade (E) over the Cup, line С up the mounting hole on the Cup A. Pass the supply wires through Inner Backplate (A). Attach Inner and the hole on the Shade (E), Backplate (A) to Outlet Box with the head of Green Ground Screw Cup secure by threading the Lock facing you. Secure it with Outlet Box Screws (not included). Tighten Screw (F) onto the mounting hole. until snug. Hand tighten until sung. B. Race all supply wires through the Inner Backplate (A) as shown. B. This fixture uses Medium Base F Refer to Step 2 for wiring connections. Decorative Filament 60W bulb C. Attach Fixture Body (C) over Inner Backplate (A) and secure with (D). Maximum 100W. Insert bulb Ó Lock Screws (B). Tighten until snug with screwdrivers. and screw snugly into place. Your fixture is now assembled and Щ ready to use. Enjoy! Outlet Box С Е Figure 3 D Figure 1 İ. В Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com February 2016 © 2016 Quoizel Inc. 1of2

ANW8603AN		
FINISH: ANTIQUE		
1	22" — 5"Dia. (2)	
	7"→	
(3)Medium Base	NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/4"	
Decorative Filament 60W	NO. PART NUMBERREPLACEMENT PART DESCRIPTIONQTY.1G12444SHGLASS SHADE3	
bulbs (provided), Maximum 100W.	2 I1101EC VINTAGE BULB 3	
	Thank you for nurchasing a Quoizel product	

February2016